

HOW TO DRILL YOUR CUTTING BOARD

THINGS YOU'LL NEED:

- A drill
- 1/2" drill bit (this will give some play)
- A clamp
- Marker
- **Safety goggles**

STEPS:

1. **Put on goggles**
2. If your old board's holes do not go all the way through the board, use a ½ " drill bit and finish drilling them all the way through the old board.
3. Place your new board on a flat surface, with a flat scrap block underneath that you can drill into.
4. Place the old board on top of the new board and align, if the new board is larger make sure you align accordingly.
5. When you have them aligned, mark both holes(this will help you align after the first hole) use the clamp to clamp them together, as soon as you make a starter hole, you can move the old board out of the way while you finish.
6. Align the holes again and repeat for the second hole.
7. Sanitize your new board and enjoy.